

Dial or

North-south lines or orienting line

Graduation ring

Compass needle Red points North



Bearing


Index

Direction of Travel Arrow

Magnifying Glass

Orienting Arrow and fluorescent dots

Follow the 1-2-3 system



Step 1 - Point the

baseplate to your destination - Place compass on map with edge along desired line of travel with the Direction of Travel arrow pointing towards your destination.

Step 2 – Set the Compass Heading

Rotate compass dial until "N" on the ring point towards magnetic North on the map.

Step 3 - Follow your Heading

With the red (north) end of the needle pointing towards "N" on the compass graduation ring, the Direction of Travel arrow points to your destination.







